

FRONT OF VEHICLE



Universal Source Mount
Drill Template

**TAPE THIS TEMPLATE IN PLACE
DRILL $\varnothing.187$ (3/16") DIAMETER
HOLES 4 PLACES WHERE SHOWN**

LEAVE ENOUGH ROOM FOR LATCHES

LEAVE ENOUGH ROOM FOR LATCHES

3.000

DRILL $\varnothing.187$ 4PL.

7.000

FRONT OF VEHICLE



Universal Source Mount
Drill Template

**TAPE THIS TEMPLATE IN PLACE
DRILL $\varnothing.187$ (3/16") DIAMETER
HOLES 4 PLACES WHERE SHOWN**

LEAVE ENOUGH ROOM FOR LATCHES

LEAVE ENOUGH ROOM FOR LATCHES

3.000

DRILL $\varnothing.187$ 4PL.

7.000