



### MAIN CONTROL SCREEN

**TOUCH TO TURN SCREEN OFF. HOLD FOR 1 SECOND TO TURN ALL ACCESSORIES OFF TOUCH IN AREA OF OFF BUTTON IS TO TURN SCREEN ON**

**“OFF ROAD” MODE ENABLES THE FLASH AND STROBE FEATURES. “ON ROAD” MODE DISABLES THE FLASH AND STROBE FEATURES.**

**SLIDER USED FOR DIMMING YOUR OFFROAD LIGHTS**

**SOURCE # INDICATOR**

**CURRENT METER (ONLY AVAILABLE WHEN USED WITH THE BANTAM)**

**SELECT TO ENTER PROGRAMMING MODE**

**SOURCE BOARD TEMP NORMAL RANGE IS BETWEEN 0 DEG F & 220 DEG F**

**BATTERY VOLTAGE MONITOR SYSTEM WILL SHUT DOWN WHEN VOLTAGE DROPS BELOW 11.2V FOR LONGER THAN 2 MINUTES MUST RESTART ENGINE TO RE-INITIALIZE SYSTEM (12.8 TO RESTART)**

### SWITCH PROGRAMMING SELECTION SCREEN

**SELECT SWITCH TO CUSTOMIZE**

**USE THIS SLIDER TO ADJUST BACKGROUND BRIGHTNESS AND SLEEP TIMER ADJUSTMENT**

**CREATE A MASTER SWITCH THAT WILL ACTIVATE ALL LINKED SWITCHES IN THE GROUP WHEN TURNED ON.**

**DEFAULT SOURCE IS 1 THIS IS WHERE YOU SELECT WHICH SOURCE TO CONTROL IF YOU HAVE MULTIPLE SOURCES. YOU MAY ALSO SWIPE LEFT OR RIGHT TO CHANGE BETWEEN SCENES**

**USED TO PAIR TO THE BANTAM APP**

### SWITCH CUSTOMIZATION SCREEN

**SELECT EACH LINE AND ENTER TEXT. 8 CHAR. MAX PER LINE**

**USE THIS BUTTON TO ENTER INTO SWITCH FEATURE SCREEN**

**TOUCH SAVE BUTTON WHEN DONE AND WAIT 1 SECOND FOR BUTTON TO FLASH RED TO SAVE**

### SWITCH FEATURE SCREEN

**PLEASE BE SURE TO ABIDE BY YOUR STATE LAWS WHEN USING FEATURES SUCH AS STROBE AND FLASH.**

## “OFF ROAD” / “ON ROAD” MODE:



Selecting the “Off Road” mode enables you to use all of the flash and strobe features that you have programmed to use for certain switches (in the “Switch Feature Options” menu).



Selecting the “On Road” mode disables all the flash and strobe features. Switching to “On Road” will change ALL switches currently in flash or strobe mode to solid on.



## LINK

The “Link” option allows you to turn on multiple switches with one (Master) switch.

1. In the “Switch Programming Selection Screen” start by pressing “Link”



**NOTE** Strobe function must be turned off before you go back into the setting to disable it. If it's left on, then the strobe function will not be disabled.

2. Click on any switch to program it as the Master switch



**NOTE** You can still use all grouped switches individually, but turning on the master switch will turn on all switches in the group.

3. Click on all switches you wish to link the Master switch



**PLEASE BE SURE TO ABIDE BY YOUR STATE LAWS WHEN USING FEATURES SUCH AS STROBE AND FLASH.**

4. Then click “Link” and “Back”

## SWITCH ICON CUSTOMIZING

The sPOD Bantam app will allow the buttons to be customized.

In Google Play (for Android) or iTunes (for Apple), search “sPOD Bantam”.

Download the sPOD Bantam app onto your smartphone or tablet.

Be sure that your device’s Bluetooth is turned on.



1. With the app closed and off, press the “Pair” button to put the Touchscreen in “pairing mode” for 60 seconds.
2. Open the Bantam app and touch “Setup”.
3. Touch the “Scan” button and wait 10 seconds.
4. Hit “Cancel” and wait about 10 seconds for the PIN to appear in upper left (in red).
5. Touch the “Setup” button.
6. Touch the “Scan” button and wait 10 seconds.
7. When “Pairing Request” dialogue box appears, enter PIN number and then touch the Pair button. The app will now be paired to the Bantam and will be ready to use. To reset pairing with all devices, touch and hold the “Reset” button for 10 seconds.

## CALIBRATION

1. Use a small flathead screwdriver to pull off the small plug. This will expose the calibration button on the back
2. While touchscreen is plugged in, press the white calibration button that is inside the access hole
3. Follow the instructions on the screen, touching the screen where shown
4. Replace the plug when finished



Plug



Calibration Button

**IF TOUCHSCREEN GOES INTO SLEEP MODE, TAP THE UPPER LEFT CORNER OF THE SCREEN.**